


Township of North Brunswick  
- Flood Zones -

**Legend**

- BASEMAP
- - - EASEMENTS
- ▭ MUNICIPAL BOUNDARIES



The special flood hazard areas, as determined by the Federal Emergency Management Agency (FEMA), are defined as follows :  
The 1% annual flood (100 year flood), also known as the base flood, is the flood that has a 1% chance of being equaled or exceeded in any given year. The Special Flood Hazard Area is the area subject to flooding by the 1% annual chance flood. Areas of Special Flood Hazard include Zones A, AE and AO. The Base Flood Elevation is the water-surface elevation of the 1% annual chance flood.

**FLOOD ZONES**

-  0.2% Annual chance flood hazard
-  A - No Base Flood Elevations determined
-  AE - Base Flood Elevations determined
-  AO - Flood depths of 1-3 FT (usually sheet flow on sloping terrain); average depths determined.

